

3 System Component Description

STANDARD FOAMPRO 1600/1601 EQUIPMENT

The following components are packaged with the FoamPro 1600/1601:

1. Control Module with Instructions
2. Molded Cables
3. Foam Pump Assembly
4. Low-Level Sensor (One required. **Not packaged with the unit. Order separately.**)
5. Calibrate/Inject Valve with Bushing (Attached to the pump outlet connection.)
6. Inlet Line Strainer with Nipple
7. FoamPro 1" bore x 1-1/2" NPT size, 1-1/2" or 2" NPT Paddlewheel Flowmeter or 1-1/2" or 2" Foam Manifold with Paddlewheel Flowmeter and Waterway Check Valve
8. 1/2" NPT Foam Injection Check Valve (This NFPA required check valve prevents water from back flowing into foam systems.)

